

Bahama Shutters Installation Guide

Top Hinge - Hole spacing for screws - 2" from each end and 6" on center. Use Tapcon #8 (3/4" length).



Telescoping Arms
Install 6" from bottom or
at installer's discretion.

Installation Steps:

#1 - Install screws into top hinge (*see Top Hinge caption*)

#2 - Interior Locking Bracket (1) to (3) brackets may be used dependent on size opening and at installer's discretion (*see Locking Bracket caption*)

TIP- Pull Screen shut and hold tightly closed before drilling slide pin holes for best fit/hole placement.

#3 - Install telescoping arms (*see Telescoping Arms caption*)



Locking bracket (interior install) - Placement: screens 24" and smaller (1 bracket supplied) are center installed. Screens 24" and larger (2 or 3 brackets supplied) are installed 6" from each end, and if 3rd bracket provided install in the center. Fasten aluminum locking bracket to bottom of screens and drill hole (5/16" dia. x 1/2" deep) into sill to slide pin down into.



Bahama Screens and Doors[®]

A CGS Sales Company

Bahama Screens[®]
3672 Silliman St.
New Waterford, Ohio 44445

Contact information

Phone: (305) 962-6581
Email: sales@bahamascreensanddoors.com
Web: bahamascreensanddoors.com

